



ZABJ-22PA Parts Breakdown

Toll Free: 1-800-579-8088 Web: www.zinko.com

REV 103107Page 1 of 2

Jack Assembly

No.	Description
1	BODY ASSY
2	RAM ASSY
3	*STUFFING RING
4	*CYLINDER PACKING
5	SNAP RING
6	*RAM PACKING SEAT
7	*RAM BACKUP RING
8	*RAM PACKING
9	RAM PACKING STOPPER
10	VERTICAL PIN
11	HORIZONTAL PIN
12	RAM SPRING
13	RAM SPRING STOPPER
14	VALVE BALL
15	VALVE SPRING
16	VALVE PLUG
17	RELEASE STEM
18	*RELEASE PACKING
19	SAFETY VALVE BALL

No.	Description
20	SAFETY VALVE BALL SEAT
21	SAFETY VALVE SPRING
22	ADJUSTING SCREW VALVE
23	SAFETY VALVE PACKING
24	PUSH NUT
25	AIR VENT ASSY
26	RELEASE HANDLE
27	AIR PUMP ASSY
28	OIL PLUG
RP	REPAIR KITS (ALL * ABOVE)

