




# ZAPJ Series Parts Breakdown

Toll Free: 1-800-579-8088 Web: [www.zinko.com](http://www.zinko.com)

REV 103107  
Page 1 of 2



Part #	Description
9060220P-1	Body Assy
9060220P-2	Ram
9060220P-3	Adj. Screw
9060220P-4	Stuffing Nut
9060220P-5	*O-Ring
9060220P-6	*O-Ring
9060220P-7	*Dust Seal
9060220P-8	*Backup Ring
9060220P-9	*Ram Packing
9060220P-10	Ram Guide Ring
9060220P-11	Ram Snap Ring
9060220P-12	Release Stem
9060220P-13	*Release O-Ring
9060220P-14	*Oil Plug
9060220P-15	Plug

Part #	Description
9060220P-16	Valve Spring
9060220P-17	Screw
9060220P-18	Valve Ball
9060220P-19	S.V. Packing
9060220P-20	Ball Sheet
9060220P-21	S.V. Spring
9060220P-22	Adj. Screw
9060220P-23	S.V. Ball
9060220P-24	Push Nut
9060220P-25	Spring
9060220P-26	Spring Hanger
9060220P-27	Air Pump Assy
9060220P-28	Elbow
9060220P-29	Air Valve Assy
9060220P-30	Coupler

Part #	Description
9060220P-31	Air Hose
9060220P-32	Handle A
9060220P-33	Handle B
9060220P-34	Screw
9060220P-35	Nut
9060220P-36	Spring Washer
9060220P-37	Attachment
9060220P-38	Shaft
9060220P-39	Wheel
9060220P-40	E-Ring
9060220P-41	Bolt
9060220P-42	Spring Washer
9060220P-43	*Adapter A
9060220P-44	*Adapter B
9060220P-45	Spacer
9060220S-106	Repair Kits (All *)

\*43/44 adapter are optional parts.

