




ZAR Series Parts Breakdown


Toll Free: 1-800-579-8088 Web: www.zinko.com

REV 091807

ZAR-023



#	Description
1	Cylinder
2	*Cap Seal
3	*Brass Bushing
4	Ram
5	Bolt
6	Screw and Nut
7	Nut
8	Coupling Bolt
9	Dust Cap
RP	Repair Kits (all*)



ZAR-044SP & ZAR-045SP

#	Description
1	Cylinder Base
2	*O-Ring
3	Cylinder
4	Screw
5	Spring
6	Nut
7	Snap Ring
8	Bushing
9	*Cup Seal
10	*Backup Ring

ZAR-106SP & 1010SP

#	Description
11	Brass Bushing
12	*O-Ring
14	Piston Rod
15	Spring Ring
16	Fasten Nut
17	Ram Sleeve
18	Spacer
19	Pin
20	Coupler 1/4" L type
RP	Repair Kits (all*)