




ZBR-20A Parts Breakdown

Toll Free: 1-800-579-8088 Web: www.zinko.com

REV 091807



Part #	Description
1	Body
2	Spring
3	O-Ring
4	Backup Ring
5	End Plug
6	Steel Ball
7	Screw Pin
8	O-Ring
9	Backup Ring
10	Screw
11	Nut
12	Top Bar Handle

Part #	Description
13	Washer (Large)
14	Long Shaft Piston
15	Washer (Small)
16	O-Ring
17	Backup Ring
18	U-Cup Seal
19	Plunger
20	Shovel
21	Screw Pin
22	Washer
23	Switch (Male)
24	Switch (Female)

Part #	Description
25	Spring
26	Screw Pin
27	Right Feet
28	Left Feet
29	Screw
30	Claw
31	Axel
32	Link Rod
33	Washer
34	Screw Pin
35	Hook Screw Pin
36	Screw Pin

Part #	Description
37	Screw Pin
38	Backup Ring
39	O-Ring
40	Steel Ball
41	Spring
42	Screw Pin
43	Cylinder
44	Plunger
45	Support Bar
46	Handle