




ZHP-180 Parts Breakdown

Toll Free: 1-800-579-8088 Web: www.zinko.com

REV 101607



#	Description
2	O-Ring
3	Backup Ring
4	O-Ring
5	Backup Ring
6	Pump Piston
7	Screw
8	Screw
9	Steel Ball
10	Steel Ball
11	O-Ring
12	Release Valve

#	Description
13	Steel Ball
14	Bearing
15	Spring
16	Washer
17	Screw
18	Bearing
19	Steel Ball
20	Cover Screw
21	Steel Ball
22	Steel Ball
23	Pin

#	Description
24	E-Ring
25	Pin
26	Handle
27	Screw
28	O-Ring
29	Reservoir
30	Fill Plug
31	O-Ring
32	Gasket
33	Nipple