




# ZHS-150 Parts Breakdown

Toll Free: 1-800-579-8088 Web: [www.zinko.com](http://www.zinko.com)

REV 100107



| Part #    | Description             |
|-----------|-------------------------|
| 9130150-1 | Legs                    |
| 9130150-2 | Fixing Plate for Tripod |
| 9130150-3 | Screw                   |
| 9130150-4 | Spring Washer           |
| 9130150-5 | Nut                     |
| 9130150-6 | Link Plate              |
| 9130150-7 | Upper Fixing Strip      |
| 9130150-8 | Screw                   |
| 9130150-9 | Screw                   |

| Part #     | Description         |
|------------|---------------------|
| 9130150-10 | Spring Washer       |
| 9130150-11 | Nut                 |
| 9130150-12 | Middle Fixing Strip |
| 9130150-13 | Lower Fixing Strip  |
| 9130150-14 | Screw               |
| 9130150-15 | Thread Rod          |
| 9130150-16 | Tube                |
| 9130150-17 | Fixing Pin          |
| 9130150-18 | Connecting Chain    |

| Part #     | Description   |
|------------|---------------|
| 9130150-19 | T-Bearing     |
| 9130150-20 | Adjust Handle |
| 9130150-21 | Saddle        |
| 9130150-22 | Screw         |
| 9130150-23 | Pad           |
| 9130150-24 | Washer        |
| 9130150-25 | Screw         |
| 9130150-RP | Repair Kits   |