



# ZJJ Series Parts Breakdown

Toll Free: 1-800-579-8088 Web: [www.zinko.com](http://www.zinko.com)

REV 113007

	DESCRIPTION
	PARTS ROOT NO.
01	CAP
02	HEX BOLT
02a	SPRING WASHER
03	KEY
04	LIFTING SCREW
05	RAM
06	NUT
07	GREASE FITTING
08	SHELL
09	WORM GEAR
10	BEARING HOLDER
11	END KEY
12	BEARING
13	BASE
14	CARRYING HANDLE
15	WORM
16	WORM BEARING
17	BUSHING
18a	CAP-A
18b	CAP-B
19	OIL SEAL
20	RATCHET WHEEL
21	RATCHET PLUNGER
22	RATCHET HANDLE CASE
23	FLAT HEAD BOLT
24	SET SCREW
25	SET SCREW
26	SNAP RING
27	SET SCREW
28	SET SCREW
29	HANDLE PIN
30	SPIRIT PIN
31	SET SCREW
32	SNAP RING
33	LINER
34	SPRING
35	COVER PLATE
36	MACHINE SCREW
37	SNAP RING
38	WASHER
39	STEEL BALL
40	SPRING
41	GREASE FITTING
42	HANDLE BAR
43	SPACER

**Model No.**  
**100 TON - ZJJ-10011**

