




ZN-12T Parts Breakdown

Toll Free: 1-800-579-8088 Web: www.zinko.com

REV 091907



No.	Description
1	Main Body
2	Screw, Extension
3	Sleeve
4	Ram
5	Ram Packing Seat
6	*Ram Backup Ring
7	*Ram O Ring
8	Washer
9	C Ring
10	Dust Ring
11	*O Ring
12	Stop Ring

No.	Description
13	Socket
14	Plunger
15	Pin
16	Snap Ring
17	Pin
18	*Backup Ring
19	*O Ring
20	Steel Ball
21	Spring
22	Screw
23	Spring Guide
24	Screw

No.	Description
25	*O Ring
26	Release Valve
27	Filter
28	Spring
29	Screw
30	Plug
31	Handle Bar
32	Base
33	Cylinder
34	U Plate
35	Handle
RP	Repair Parts (All *)