



ZPJ-800 Parts Breakdown

Toll Free: 1-800-579-8088 Web: www.zinko.com

REV 091807

#	Description
1	Base
2	Backup Ring
3	Cylinder
4	Oil Seal
5	Backup Ring
6	Link Rod
7	Raise Arms
8	Foot Plate
9	Socket Bolt
10	Steel Ball
11	Oil Seal
12	Release Valve Spindle
13	Filler Screw
14	Filler Screw
15	Aluminum Washer
16	Valve
17	Oil Seal
18	Cup Washer
19	Pump Cylinder
20	Oil Seal
21	Backup Ring
22	Piston
23	Oil Seal
24	Oil Plug
25	Oil Seal
26	Oil Seal
27	Plain Washer
28	Hex Bolt
29	Handle Set
30	Handle Socket Ass'y
31	Socket Bolt
32	Handle Socket Ass'y
33	Socket Bolt
34	Socket Bolt
35	Nut Housing
36	R-Pin
37	Oil Seal
38	Reservoir End Cap

