




ZR Series Parts Breakdown

Toll Free: 1-800-579-8088 Web: www.zinko.com

REV 091807



Item #	Description
1	Thread Protector
2	*Wiper
3	Bearing Stop Ring
4	Bearing Sleeve
5	Saddle
6	*Stop Ring
7	Screw
8	*Washer
9	Plunger

Item #	Description
10	Seating Nut
11	Spring
12	Rod Bearing
13	*Washer
14	Bearing
15	*U-cup
16	C-ring
17	Cylinder
RP	Repair Kits (All *)