




ZR-252 & ZR-254 Parts Breakdown

Toll Free: 1-800-579-8088 Web: www.zinko.com

REV 091807



No.	Description	No.	Description
1	Cylinder	10	Washer
2	Screw	11	Stop Ring
3	*Hydraulic Couplers	12	Piston Rod
4	Screw	13	Rod Wiper
5	Washer	14	*Shelter Dust
6	Return Spring	15	O-Ring
7	C-Ring	16	Cylinder Cap
8	*Backup Seal	17	Cylinder Cover
9	*Back Seal	RP	Repair Kits (All *)